

# Solving the Nitrogen Problem

## Our Presenter

# David Lepre

**David Lepre, P.E.**, is a Sales Engineer with Orenco Systems®, Inc., a wastewater equipment manufacturing firm based in Sutherlin, Oregon. In this role, he manages wastewater projects and provides engineering assistance to commercial and municipal designers and engineers throughout his territory. David came to Orenco in 2007 with a strong background as a consulting engineer. He previously designed wastewater and stormwater systems for Otak, a multidisciplinary engineering firm. Since joining Orenco, he has specialized in designing effluent sewers and treatment systems for nutrient reduction.

David has a Bachelor of Science degree in civil engineering from the Oregon Institute of Technology and is licensed as a Professional Engineer in Oregon. In his spare time, he enjoys spending time with his family and coaching his six sons in sports.

# Overview

- Why is nitrogen a problem?
- Why use a packed-bed filter for nitrogen removal in wastewater?
- How does the nitrogen cycle work?
- What factors affect nitrogen treatment?
- How do I set up a packed-bed filter to effectively treat nitrogen?

# Nitrogen

- Nitrogen ( $N_2$ ) is a colorless, tasteless, and generally inert gas.
- Air, by volume, is composed of about 78.08% nitrogen.
- Nitrogen is assimilated from the air in living things.

# Nitrogen Regulations

- Toxicity
- Eutrophication
- Drinking water standards



"Court Gavel - Judge's Gavel - Courtroom" by weiss\_naarz\_photos is licensed under [CC BY-SA 2.0](#).

# Introduction to the Packed-Bed Filter (PBF)


PBF designs have been used for decades to reduce nitrogen in wastewater systems, from systems at individual homes all the way up to large commercial systems.






# Two General Types of Treatment: Suspended and Attached Growth

**Attached growth**




**Suspended growth**



# Maryland Bay Restoration Fund Study

- In 2009, President Obama issued an executive order to clean up the Chesapeake Bay.
- Each state (7 total) contributing to the eutrophication of Chesapeake Bay, with the help of the EPA, put together a Watershed Implementation Plan (WIP).
- Maryland, which collects a tax to publicly fund decentralized treatment systems, put together a testing program for various wastewater systems.





# Maryland Bay Restoration Fund Study, cont.

- Maryland's third-party "Best Available Technology" field-testing document:

<https://mde.maryland.gov/programs/Water/BayRestorationFund/OnsiteDisposalSystems/Documents/BAT%20Ranking%20Document.pdf>

- Matrix shows cost/lb of TN removed, electrical consumption, etc.
- PBFs were consistently ranked as the most cost-effective technology.

# Comparing Treatment Performance (2019)

Vendor in Ascending Order	Mean % Reduction TN (Using 60 mg/L Influent)	Mean Effluent Concentration (mg/L)
AdvanTex AX20RT	76%	14
AdvanTex AX20	71%	17
SeptiTech M40D	67%	20
Hoot BNR	64%	21
RetroFast	58%	25
Singulair TNT	55%	27
Singulair Green	55%	27


# Comparing Treatment Performance (2019)

Vendor	Price Per Pound of N Reduced
AdvanTex AX20RT	\$95.81
AdvanTex AX20	\$94.84
Hoot BNR	\$100.16
RetroFast	\$103.86
Singulair TNT	\$95.01
Singulair Green	\$95.01
SeptiTech M40D	\$108.31

# Comparing Treatment Performance (2019)


Vendor	1 Year Electrical Consumption (represented as kWh/ year)	Increased Electrical Costs Per Year Assuming \$0.14 Per kWh
AdvanTex AX20	210.2	\$29.43
AdvanTex AX20RT	210.2	\$29.43
Hoot BNR	765.77	\$107.21
Singulair TNT	979.66	\$137.15
Singulair Green	979.66	\$137.15
SeptiTech M40D	1741.05	\$243.75
RetroFast	1401.6	\$196.22

# Typical PBF Recirculation Configuration





# Effective Design of the PBF



Textile


Sand

Gravel

# Nitrogen in Wastewater

Contribution percentages for domestic waste


- 75% from urine
- 20% from feces
- 5% from other agents




# Nitrogen in Wastewater

- Organic nitrogen ... Organic-N
- Ammonium nitrogen ...  $\text{NH}_4\text{-N}$
- Ammonia nitrogen ...  $\text{NH}_3\text{-N}$  (un-ionized)
- Nitrite nitrogen ...  $\text{NO}_2\text{-N}$
- Nitrate nitrogen ...  $\text{NO}_3\text{-N}$

# Ideal Nitrogen Treatment Process



# Ammonification





# Nitrification



# Nitrification

In the first phase, ammonium-oxidizing autotrophic bacteria known as nitrosomonas convert ammonium to nitrite:




In the second phase of nitrification, a nitrite-oxidizing bacteria known as nitrobactor converts nitrite to nitrate:




# Nitrification ... What's Needed

- Adequate aeration volume
- Sufficient aeration capacity
- Sufficient alkalinity/pH
- No significant toxicity
- Temperature

# Nitrification Reaction Rate vs BOD/TKN



# pH Effect on Nitrification





# Alkalinity Demand & Need

Used to determine how much supplemental alkalinity is needed

## Equation B3

$$\text{Alkalinity Demand} = \text{TKN}_i \text{ mg/L} \times \frac{5 \text{ mg/L Alkalinity}}{1 \text{ mg/L TKN}}$$

## Equation B4

$$\text{Alkalinity Need} = \text{Alk Demand} + \text{Target Residual Alk} - \text{Influent Alk}$$

### Example

*PTE values of 80 mg/L TKN and 160 mg/L Alkalinity in waste stream*

*Target residual of 100 mg/L alkalinity*

*Determine the amount of alkalinity required to buffer the treatment process*

*Solving for Equation B3:*

$$\text{Alkalinity Demand} = 80 \text{ mg/L} \times \frac{5 \text{ mg/L Alkalinity}}{1 \text{ mg/L TKN}} = 400 \text{ mg/L Alkalinity}$$

*Now solving for Equation B4:*

$$\text{Alkalinity Need} = 400 \text{ mg/L} + 100 \text{ mg/L} - 160 \text{ mg/L} = 340 \text{ mg/L}$$

Therefore the system will require supplemental alkalinity addition to buffer the treatment process.

# Nitrogen Considerations

- Typical forms of alkalinity
  - ~ Soda ash (sodium carbonate)
  - ~ Magnesium hydroxide
  - ~ Quicklime

# Denitrification

- Denitrification is the microbial utilization of nitrate under anoxic conditions. (DO < 0.3 mg/L is preferred.)
- Denitrification is a multi-stage process where nitrate ( $\text{NO}_3^-$ ) is reduced to nitrogen gas ( $\text{N}_2$ ), which is liberated back into the atmosphere after rising to the liquid surface in tiny bubbles.

# Denitrification

Anoxic denitrification conversion in wastewater can be expressed by the following reaction:




Microbial denitrification consumes 4 mg carbon for each mg nitrate utilized.

The rule-of-thumb in wastewater applications, though, is to use a BOD/NO<sub>3</sub><sup>-</sup> range between 4:1 and 8:1.


Also, denitrification recovers 3.57 mg alkalinity (CaCO<sub>3</sub>).

# Effect of DO on Denitrification






# Temperature Effect on Nitrogen Processes



# Nitrogen Considerations

- Toxins must be eliminated
  - ~ Water softeners
  - ~ Commercial applications with heavy cleaners
  - ~ Other sources

# Realistic Nitrogen Treatment Process




# Oxygen Availability in Air



# Packed-Bed Filter Biofilms


- Oxygen is diffused from the air
- CBOD is met in the upper levels of the media
- Ammonification happens in the lower regions




# Typical Effluent Quality

- Varies by permit and effluent dispersal method
- Single-stage configuration with domestic-strength wastewater:
  - ~ Target < 10 mg/L BOD<sub>5</sub> and TSS
  - ~ > 60% TN reduction
  - ~ > 95% ammonia removal
- Two stage configuration:
  - ~ Strict ammonia limits (> 95% removal)
  - ~ Not to exceed limits of < 10 mg/L BOD<sub>5</sub>
  - ~ 30-day average limits of ≤ 5 mg/L BOD<sub>5</sub>
- Advanced nitrogen removal configuration:
  - ~ > 60% TN reduction

# Standard – Removal of Organics




# Advanced Removal of Nitrogen





# Moving Bed Bioreactors for Denitrification



## Components (as shown):

- |                     |                           |
|---------------------|---------------------------|
| ❶ Pressurized inlet | ❹ Tank top                |
| ❷ Pneumatic ejector | ❺ Screened outlet box     |
| ❸ Air feed line     | ❻ Gravity outlet          |
| ❹ Air feed manifold | ❼ Media                   |
| ❺ Tank wall         | ❽ Lifting bracket (4 ea.) |

To reach concentrations below 10 or 20 mg/L, MBBd units are available from Orenco.

# Test Center Summary

<b>AdvanTex® Effluent Averages</b>	<b>Total N mg/L</b>	<b>NH<sub>3</sub>-N mg/L</b>	<b>Total P mg/L</b>	<b>Duration</b>
NSF/ANSI Standard 40	12 (64%)	0.9 (96%)	-	7 months
NSF/ANSI Standard 40 Testing with UV	13 (66%)	1.1	-	6 months
Novatec Nitrogen Removal Testing	10 (70%)	-	-	1 year
Rotorua District Council Approval Testing	14(78%)	0.2 (99%)	8 (36%)	13 months
Rotorua 2010	12.7 (78%)	0.6 (96%)		

# Field Testing Summary

AdvanTex Effluent Averages (no. of SFRs)	Total N mg/L	NH <sub>3</sub> -N mg/L	Total P mg/L	Duration
NSF Pennsylvania Testing Program (11)	17 (68%)	1.7 (96%)	-	1-3 years
Virginia Approval Testing Program (13)	15	1.8	-	18 months
Jefferson County, CO Health Dept Permit Testing (43)	15	-	-	2 years 7 months
Skaneateles, NY Demonstration Project (2)	14	0.9	10	2 years 2 months
La Pine, OR Demonstration Project (3)	17 (74%)	1.9	9 (18%)	2 years 7 months
Rhode Island Demonstration Project (5)	18	-	9	1 year 4 months
Maryland BAT Testing AX20 (12)	17			1 year 5 months
Maryland BAT Testing AX20RT (12)	14	1.3		1 year

# Meridian School Data

- Influent average  
TKN = 129 mg/L
- Effluent Average  
TN  $\leq$  10 mg/L



# Summary

- Nitrogen treatment in wastewater protects water ways.
- Packed-bed filters are an effective way to treat for nitrogen.
- The amount of nitrogen treatment depends on the configuration.

# ***Solutions for Decentralized Wastewater Treatment***

***Orenco Systems<sup>®</sup>, Inc.***

***[www.orenco.com](http://www.orenco.com)***

***[dlepre@orenco.com](mailto:dlepre@orenco.com)***